

Document Pack

TS7702HR Vinyl Production chair



USER WEIGHT CAPACITY

techsit
TECHNICAL WORK SEATING



Pre-User Check List

Visual check that chair is as pictured below



User information

TS7702HR Vinyl Production chair

Suitable for use in manufacturing environments.



User information

Seat height



Lighten load, lift lever to adjust height, release lever to lock position.

Back rake and seat tilt



Push button to activate free-float. Push button again to lock position if wanted.

Back height



Ratchet back, lift to required height. Lift to top to release.

Headrest



Lift and tilt head rest to required position.

User information

Arm height



Press button under arm rest to adjust. Release to lock.

Arm pad depth



Slide arm pad forward and back to adjust.


Each user should adjust the chair following the user instructions, for seat height, back rack and back height.

Feet should be flat on the floor:
adjust seat height for this.

Your back should be supported and the curve of the chair-back should sit against the lumbar: adjust the chair-back height and rake for this. To fine-tune the lower back support, use the lumbar pump and seat slide.

Options

Brake loaded castors



Castors will lock when chair is loaded, this restricts movement of chair.

Lumbar pump



Squeeze bladder to inflate the lumbar support. Depress button on bladder to release.

Seat slide



Press button to move seat out or in.

Each user must do the following before each chair use:

Check the chair visually to make sure it is the same as the picture.

Look for anything that is different to the picture, i.e. missing items, broken items, loose fittings etc.

If a non-conformance is identified. Do not use the chair and report it to your line manager immediately, who can use the supplier contact details below.

Certificate of conformity

BS EN 1335-1:2020 Work chair dimensions, safety requirements, safety test methods

BS EN 5459-2:2002+A2:2008 Seating for use by persons up to 150kg

BS EN 16139:2013 Work chair strength, durability & safety

BS EN 1335-2:2018 Work chair safety requirements

BS EN 7176 Flammability specification

Guarantee

Contact **Cromwell Tools Ltd**
aerospace@cromwell.co.uk